



Dot Remote User Manual GL-RC-010



LED-Trading Tobias Ebert

Schoeneicher Str. 42, Schoeneiche b. Berlin, Germany, 15566

0049 30 641 689 17 info@led-trading.de

Product Parameter

Model: GL-RC-010
Input voltage: 3V (CR2450)
Standby current: <10uA
Frequency: 2.4GHz
Wireless transmission power: 6dB
Operating temperature: -10°C~40°C
Material: PC
Size: 49.9x49.9x16mm



How to use



Press down from the top of the remote control with your finger to trigger the button.


Connect/Disconnect remote control

The light needs to be paired with the remote control before it can be controlled.

1. Pairing (coding) method:

- 1) Turn off the light, and turn it on after 10 seconds.
- 2) Press the button once within 3 seconds after turning on the light. If the coding is successful, the light will flash (please refer to the light's manual

for the specific status of the light. After the PRO series is paired, the light will turn green, and the RF will flash 3 times). If the coding fails, repeat the above steps.



within 3 seconds short press 1 times

Note:

A light can be paired with up to 4 remote controls. When the 5th remote control is paired with it, the first paired remote control will automatically become invalid.

2. How to disconnect (clear the code) the pairing:

- 1) Turn off the lamp and wait for 10 seconds.
- 2) Quickly press the button three times to enter the automatic clearing code mode (the clearing code mode lasts for 5 seconds, and pressing the button within 5 seconds will automatically exit the clearing code mode).



Quickly press the button three times

- 3) Turn on the lamp. If the code clearing is successful, the lamp will blink (please refer to the lamp's manual for the specific status of the lamp. The Pro series blinks 3 times, and the RF blinks 9 times).

If the clearing fails, repeat the above steps.

Button control

1. Power on/off

Press the button once to turn on/off the lamp connected to the remote control.



2. Color switching

Quickly press the button twice to switch colors. The colors cycle through the following 9 colors (warm white - cool and warm white - cool white - red - green - blue - yellow - light blue - purple).

3. Brightness adjustment

Long press to trigger brightness adjustment. If the current long press is to increase the brightness, then releasing and pressing again for a long time will decrease the brightness, and vice versa.

Indicator light

When the remote is pressed, the red indicator light turns on;

when it is released, the indicator light goes off.





Note: The indicator light can only be seen clearly in a dark environment.

Do not hit the remote hard, do not put heavy objects on the product, as it may cause damage to the device.

Install button battery steps

1

Rotate counterclockwise according to the arrow on the back of the product to unlock





2

Open the product bottom cover

3

Insert a new button battery (CR2450)

*The positive side of the button battery should face up




4

Rotate clockwise according to the arrow on the back of the product to lock installation is complete

5

When replacing the button battery, use a flathead screwdriver to remove the old battery



Note: The product does not include button battery (CR2450).



Attention

1. Please use batteries of the correct size, otherwise, it may cause the product to malfunction.
2. Please handle waste batteries properly to avoid environmental pollution.
3. The working temperature of the product is -10-40°C, please do not use the product in areas with direct sunlight, humidity, high temperature, etc.
4. Please do not use the product in metal shielding areas and strong magnetic field areas, otherwise, it will seriously affect the wireless signal transmission of the product.

Disclaimers

1. Our company will update the content of this manual according to the product upgrade, and the update will be displayed in the latest version of this manual without further notice.
2. Due to our company's continuous adoption of new technologies, if there are changes in product parameters, there will be no further notice.
3. This manual is for reference and guidance only, and does not guarantee to be completely consistent with the actual product. The actual application shall prevail based on the actual product.
4. The components and accessories described in this manual do not represent the standard configuration of the product. The specific configuration shall be based on the actual product.
5. All text, tables, and pictures in this manual are protected by relevant national laws and may not be used without our company's permission.