
## 55 X 440 MM 80g 超白哑粉纸 黑白双面印刷 风琴折


Instruction Manua 55


Enjoy Our Smart Life




- · Bitte scannen Sie den QR-Code hier für eine Anleitung in deutscher Sprache
- · Por favor escanear el código QR aguí para instrucciones en español
- Veuillez scanner le QR code ici pour des instructions en
- Пожалуйста, отсканируйте QR-код здесь, чтобы получить инструкции на русском языке.
- Leia o código QR aqui para obter instruções em português
















55

后面





Remote Mode

Scenario Mode

Single Press

Long Press >3s

Rotate

Single Press

Double Clicks

Long Press

Rotate to Left







1. During the free warranty period, if the product breaks All products marked with the symbol for separate collection down during normal use, we will offer free maintenance for the product

2.Natural disasters/man-made equipment failures, disassembly and repair without the permission of our company, no warranty card, products beyond the free warranty period, etc., are not within the scope of free warranty

3.Any commitment (oral or written) made by the third party (including the dealer/service provider) to the user beyond the warranty scope shall be executed by the third party 4.Please keep this warranty card to ensure your rights 5. Our company may update or change the products without

Please refer to the official website for the updates.

## CYCLING INFORMATION

of waste electrical and electronic equipment (WEEE Directive 2012/19 / EU) must be disposed of separately from unsorted municipal waste. To protect, your health and the environment, this equipment must be disposed of at designated collection points for electrical and electronic equipment designated by the government or local authorities. Correct disposal and recycling will help prevent potential negative ... consequences for the environment and human health. To find out where these collection points are and how they work, contact the installer or your local authority.

